



TSB-CSC02

Safe CSC Handling Procedure

To prevent the Concentric Slave Cylinder (CSC) from failing it is important that you follow the simple guidelines whilst handling and/or fitting the cylinder to the vehicle.

When handling the new CSC never compress the cylinder prior to fitment in the vehicle. By working the cylinder it can potentially damage the internal seals causing the cylinder to fail.





In some applications compressing the cylinder can dislodge the rear seal of the cylinder (see picture below)

















